
INSTRUCTION MANUAL – 2-PERSON GOURMET SET + BURNERS

Item number: 23460220

Version: 1.0

Date: March 2026



1. Introduction

Congratulations on your purchase of this gourmet set. Please read this manual carefully before use to ensure safe and correct operation.

2. Product specifications

- Type: Gourmet set with burners
 - Capacity: 2 people
 - Heat source: Burners (gel fuel/liquid fuel)
 - Intended use: Domestic use (indoors)
-

3. Contents of the pack

- 1x Gourmet set
 - 2x pans
 - 1x set of burners
-

4. Safety instructions

- Use only in well-ventilated areas.
 - Never leave the appliance unattended whilst in use.
 - Keep at least 1 metre away from flammable materials.
 - Keep out of reach of children.
 - Use only recommended fuels.
 - Do not move the appliance whilst it is in use or whilst it is hot.
-

5. Installation and preparation

1. Place the gourmet set on a stable, heat-resistant surface.
 2. Check that all parts are correctly assembled.
 3. Fill the burners in accordance with the fuel supplier's instructions.
 4. Ensure there is adequate ventilation.
-

6. Use

1. Light the burners with a long match or a lighter.
 2. Allow the appliance to heat up for 5–10 minutes.
 3. Place food in the pans.
 4. Use heat-resistant cookware.
-

7. After use

1. Extinguish the burners completely.
 2. Allow the appliance to cool down completely.
 3. Clean with a soft cloth and a mild detergent.
-

8. Risks and hazards

- Fire hazard due to open flames
 - Risk of burns
 - Carbon monoxide build-up in the event of poor ventilation
 - Risk of explosion if fuel is used incorrectly
-

G. Maintenance

- Clean after each use
 - Check burners for leaks or damage
 - Do not use corrosive cleaning products
-

10. Restrictions on use

- For domestic use only
- Do not use in caravans, tents or small enclosed spaces
- Not suitable for professional use

11. Liability

The manufacturer accepts no liability for damage caused by incorrect use or failure to follow these instructions.
