
I INSTRUCTION MANUAL – TABLE GRILL

Item number: 23453002

Version: 1.0

Date: March 2026



1. Introduction

Thank you for your purchase. This table grill is designed for safe and efficient indoor use.

2. Product specifications

- Type: Electric tabletop grill
- Power supply: 220–240V ~ 50/60Hz
- Intended use: Domestic use

3. Contents of the pack

- 1x Table grill
- 1x grill plate
- 1x power cable

4. Safety instructions

- Check the appliance for damage before use.
 - Do not use a damaged cable or plug.
 - Do not immerse in water.
 - Use only on a stable surface.
 - Keep away from flammable materials.
 - Never leave unattended whilst in use.
-

5. Installation

1. Place the grill on a flat surface.
 2. Plug into an earthed socket.
 3. Ensure the cable does not come into contact with hot surfaces.
-

6. Use

1. Switch the appliance on.
 2. Set the desired temperature.
 3. Allow it to preheat for 5–10 minutes.
 4. Place food on the grill plate.
-

7. After use

1. Switch off the appliance.
 2. Unplug the appliance from the socket.
 3. Allow to cool completely.
 4. Clean the grill plate.
-

8. Risks and hazards

- Electric shock if used incorrectly
 - Risk of fire due to overheating
 - Burns from hot surfaces
 - Short circuit if water comes into contact with the appliance
-

G. Maintenance

- Clean regularly
- Check the cable and plug for wear and tear
- Use only original parts

10. Restrictions on use

- For domestic use only
 - Not suitable for outdoor use
 - Do not use without supervision
-

11. Liability

The manufacturer accepts no liability for damage caused by incorrect use or failure to follow these instructions.
